

Technical Service Bulletin


Heat Exchanger Serial Number Location

Introduction


This bulletin identifies the locations of GB142 and GB162 heat exchanger serial numbers. Identifying your product's serial number is essential for customer support and warranty claims.

GB142 series boilers

Location: The heat exchanger serial number is located in labels on the heat exchanger:




GB142 Heat Exchanger Close-up




GB162 series boilers

Location: The heat exchanger serial number is located in the rating plate on the heat exchanger:



GB162 Heat Exchanger Close-up



Buderus

Bosch Thermotechnology Corp.
50 Wentworth Ave
Londonderry, NH 03053
Tel: (866) 642-3198
Fax: (603) 965-7581
www.boschheatingandcooling.com