


**INTERIOR COMPONENTS DIAGRAM
 AQUASTAR 80**



SPARE PARTS LIST

- | | | |
|---|---|--|
| 00839 - PILOT WASHER | 23617 - REAR BURNER SHIELD RETAINING SCREW | 34316 - FRAME |
| 00869 - RETAINING NUT FOR GAS INLET FITTING | 25687 - DRAFT HOOD DEFLECTING STRIP | 34329 - HOT WATER RETURN LINE FITTING |
| 00910 - RETAINING NUT FOR COLD INLET AND HOT WATER OUTLET | 25776 - WASHER | 34332 - NG TOTAL PILOT ASSEMBLY |
| 02147 - NG GAS PILOT INJECTOR | 25779 - HEAT EXCHANGER FRAME RETAINING SCREW | 34333 - PILOT TUBE ASSEMBLY ("S" TUBE) |
| 02434 - LP GAS PILOT INJECTOR | 27126 - WASHER | 34540 - LP TOTAL PILOT ASSEMBLY |
| 05964 - GAS FITTING WASHER | 29596 - THERMOCOUPLE / ELECTROMAGNET LEAD WIRE TERMINAL RETAINING SCREW | 34552 - LP GAS REGULATOR |
| 08565 - BURNER ASSEMBLY | 29910 - INLET WATER FLOW RESTRICTOR | 34923 - HEAT EXCHANGER |
| 20887 - THERMOCOUPLE | 31851 - COLD & HOT WATER ELBOW | 37916 - WATER VALVE TO COLD INLET CONNECTING COPPER TUBING |
| 22040 - THERMOSTAT SENSING ELEMENT RETAINING SCREW | 34116 - CLIP | 37918 - WATER FILTER |
| 22045 - BURNER MANIFOLD RETAINING SCREW | 34209 - OVERHEAT THERMOSTATIC SENSOR (ECO) | 37919 - COLD WATER INLET FITTING |
| 22058 - THERMOCOUPLE RETAINING CLIP | 34296 - WATER & GAS FITTING RETAINING STRIP | 38449 - COPPER ELBOW GAS FITTING |
| 22062 - WASHER | | |
| 22349 - SCREW | | |

