

WARNING

The unit must be installed by a qualified electrician.


The unit must be grounded.

Connecting the unit to power.

Making the electrical connections

Model	Rated Voltage (V)	Rated Current (A)	Recommended Wire Size (AWG)
RP12PT	240	50	6

- Strip back the insulation on the power wires about $\frac{3}{8}$ ". Any insulation on the ground should be stripped back about $\frac{3}{4}$ "
- Feed the cable through the side or rear entry grommets, as appropriate.
- Connect the cables to the terminal block and ground stud. (diagram 4.)



When the Powerstream Pro is not within sight of the electrical circuit breakers, a circuit breaker lockout or additional local means of disconnection for all non grounded conductors must be provided that is within sight of the appliance. (REF NEC 422.31)

- Make sure that all the terminal block screws are tightened securely. Loose connections can cause wires to heat up.
- Make sure that the ground wire is wrapped around its terminal stud and into the saddle washer. The nut should be tightened securely.
- Attach the front cover and tighten the retaining screws.

Spare Parts

93793749	12 kW Heat Exchanger (Thermostatic)
93793701	Backplate
93793703	Terminal Block
93793812	Front Cover (Thermostatic)
93793723	Thermal Cut-cut
93793751	Wiring Assembly (Thermostatic)
93793709	Cable Clamps & Rubber Boot
93793752	Cover Retaining Screws
93793753	12 kW Printed Circuit Board (Thermostatic)
93793754	Nameplate
93793755	Brass Inlet Assembly

For further information ask your local dealer:

FOR SERVICE AND INSTALLATION QUESTIONS CALL TOLL FREE:

866-642-3198

www.boschpro.com

Bosch Thermotechnology Corp.
50 Wentworth Avenue,
Londonderry, NH 03053.